


1600

	GRID LOC	REF DESIG	GRID LOC										
	N-5	R11	C-6	R27	J-5	R44	M-4	R61	K-4	R78	N-5	U8	H-4
O-3	R12	E-6	R28	J-4	R45	M-4	R62	K-4	R79	N-6	U9	C-4	
O-4	R13	D-6	R29	J-5	R46	M-3	R63	K-4	R80	N-5	U10	D-4	
O-5	R14	E-6	R30	J-4	R47	M-3	R64	K-5	R81	N-5	U11	E-4	
O-5	R15	E-6	R31	J-5	R48	M-4	R65	L-6	R82	K-5	U12	F-4	
K-6	R16	K-4	R32	H-6	R49	N-4	R66	L-6	R83	K-5	U13	G-4	
K-6	R17	K-4	R33	H-6	R50	N-4	R67	M-6	R84*	H-5	U14	H-5	
G-4	R18	I-4	R34	H-6	R51	N-4	R68	M-5	R85	H-5	U15	D-6	
G-5	R19	I-4	R35	J-6	R52	O-3	R69	M-5	R86	K-5	U16	F-6	
G-5	R20	J-5	R36	L-4	R53	N-4	R70	M-6	S1	B-4	U17	G-6	
G-5	R21	H-6	R37	L-3	R54	N-4	R71	M-5	U1	C-3	U18	J-4	
G-5	R22	I-5	R38	L-3	R55	M-3	R72	N-5	U2	D-3	U19	L-5	
G-3	R23	I-6	R39	L-3	R56	N-4	R73	N-5	U3	D-3	U20	M-4	
C-6	R24	I-6	R40	L-3	R57	N-4	R74	N-4	U4	E-3	U21	M-5	
B-6	R25	J-5	R41	L-4	R58	N-4	R75	N-6	U5	F-3	U22	C-3	
C-6	R26	J-5	R42	L-4	R59	N-4	R76	N-5	U6	G-3	VR1	K-3	
			R43	L-4	R60	N-4	R77	N-5	U7	H-4	VR2	K-4	



REF DESIG	GRID LOC	REF DESIG	GRID LOC	REF DESIG	GRID LOC	REF DESIG	GRID LOC	D
C1	B-6	C17	L-4	CR4	K-4	Q13	N-5	F
C2	C-6	C18	O-3	L1	I-4	Q14	O-3	F
C3	C-6	C19	N-4	P1	K-2	Q15	O-4	F
C4	D-6	C20	M-3	P2	O-4	Q16	O-5	F
C5	E-6	C21	M-6	Q1	I-4	Q17	O-5	F
C6	E-6	C22	M-4	Q2	I-5	Q18	K-6	F
C7	I-5	C23	L-5	Q3	I-5	R1	K-6	F
C8	I-5	C24	M-5	Q4	J-6	R2	G-4	F
C9	J-5	C25	L-5	Q5	K-5	R3	G-5	F
C10	J-5	C26	O-4	Q6	K-4	R4	G-5	F
C11	J-5	C27	N-6	Q7	L-4	R5	G-5	F
C12	K-5	C28	K-3	Q8	M-3	R6	G-5	F
C13	M-4	C29	K-4	Q9	N-3	R7	G-3	F
C14	M-3	CR1	D-5	Q10	N-4	R8	C-6	F
C15	L-4	CR2	F-5	Q11	N-5	R9	B-6	F
C16	M-4	CR3	K-5	Q12	N-5	R10	C-6	F

LE MODE SWITCH ASSY

SAMPLE MODE SWITCHES (ASSY A5) TRUTH TABLE

SWITCH		OUTPUT	
REPET	HALT A ≠ B	SGL	LHA B
IN	X	X	1
OUT	IN	X	0
OUT	OUT	IN	1
			0

X = DON'T CARE. WHEN MORE THAN ONE BUTTON IS PUSHED, FUNCTION OF LEFTMOST SELECTED BUTTON IS ENABLED.






Figure 8-14.
Schematic 4, Display and Sample Mode Switches
8-17

P/O A5 SAMPLE MODE SWITCH ASSY

→ TO U1, 15



P/O A4 DISPLAY MODE SWITCH ASSY

5 15

1 → 86 8

→ 87 8

3 → 88 8


1 → 89 8


→ 90 17

1 → 91 14

MAP	LXPMP
1	
1	
1	
1	
1	
0	

)F LEFTMOST SE-





DISPLAY MODE SWITCH ASSY A4 TRUTH TABLE


SWITCH						OUTPUT					
A	A & B	A & (A⊕B)	B	NORM	EXP	HSB	LEXOR	HSA	LMAP	LXPMP	
IN	X	X	X	X	X	0	1	1	1	1	
OUT	IN	X	X	X	X	1	1	1	1	1	
OUT	OUT	IN	X	X	X	1	0	1	1	1	
OUT	OUT	OUT	IN	X	X	1	1	0	1	1	
OUT	OUT	OUT	OUT	IN	X	1	1	1	0	1	
OUT	OUT	OUT	OUT	OUT	IN	1	1	1	0	0	

X = DON'T CARE. WHEN MORE THAN ONE BUTTON IS PUSHED, FUNCTION OF LEFTMOST SELECTED BUTTON IS ENABLED.

NOTE
See Fig. 8-15 For A1
Parts Identification

REF DESIG	GRID LOC	REF DESIG	GRID LOC	REF DESIG	GRID LOC
1 J-7	U25	C-3	U69	D-1	
2 I-5	U26	D-7	U70	D-2	
3 H-7	U27	D-7	U71	D-3	
4 H-6	U28	G-4	U72	E-1	
5 H-7	U29	G-4	U73	E-1	
6 H-6	U30	G-5	U74	E-2	
7 H-8	U31	G-5	U75	E-2	
8 G-3	U32	G-6	U76	E-3	
9 C-7	U33	G-6	U77	F-1	
0 C-7	U34	G-6	U78	F-1	
1 C-8	U35	H-4	U79	F-2	
2 J-1	U36	H-4	U80	F-3	
3 I-2	U37	H-5	U81	G-1	
4 J-3	U38	H-5	U82	G-2	
5 B-1	U39	I-4	U83	G-2	
6 A-8	U40	I-5	U84	H-1	
7 C-8	U41	C-7	U85	H-2	
8 C-7	U42	C-8	U86	H-2	
9 H-2	U43	D-8	U87	I-1	
0 G-5	U44	E-8	U88	I-1	
1 C-3	U45	F-8	U89	I-2	
2 C-4	U46	G-8	U90	I-2	
3 C-4	U47	F-7	U91	J-1	
4 C-4	U48	G-7	U92	J-1	
5 C-5	U49	G-7	U93	J-2	
6 C-5	U50	I-5	U94	J-2	
7 C-6	U51	H-6	U95	J-4	
8 C-6	U52	H-7	U96	J-4	
9 C-6	U53	H-8	U97	J-5	
0 D-3	U54	I-6	U98	J-6	
1 D-4	U55	I-6	U99	E-4	
2 D-4	U56	I-7	U100	E-5	
3 D-4	U57	I-7	U101	E-6	
4 D-5	U58	J-6	U102	F-4	
5 D-5	U59	J-6	U103	F-5	
6 D-6	U60	J-7	U104	F-6	
7 D-6	U61	B-1	U105	F-1	
8 D-7	U62	B-1	U106	F-3	
9 E-3	U63	B-2	U107	G-1	
0 E-4	U64	B-2	U108	G-3	
1 E-5	U65	C-1	U109	I-4	
2 E-5	U66	C-2	U110	I-5	
3 E-6	U67	C-2	XA8P1	F-3	
4 E-6	U68	D-1	XA8P2	H-3	


ard Assembly A1



1600A-034

REF DESIG	GRID LOC	R DE								
C1	B-3	C47	H-7	J8	G-1	R20	C-8	R64	J-7	U
C2	B-4	C48	H-7	J9	G-3	R21	C-8	R65	I-5	U
C3	B-4	C49	B-1	L1	B-3	R22	G-8	R66	H-7	U
C4	B-4	C50	B-4	L2	B-4	R23	G-7	R67	H-6	U
C5	B-4	C51	B-5	L3	B-4	R24	F-7	R68	H-7	U
C6	B-4	C52	I-3	L4	B-4	R25	A-6	R69	H-6	U
C7	B-5	C53	G-3	L5	B-4	R26	C-8	R70	H-8	U
C8	B-5	C54	F-7	L6	B-4	R27	C-8	R71	G-3	U
C9	B-5	C55	E-7	L7	B-4	R28	B-3	R72	C-7	U
C10	B-5	C56	B-3	L8	B-5	R29	B-3	R73	C-7	U
C11	B-5	C57	J-3	L9	B-5	R30	B-3	R74	C-8	U
C12	B-6	C58	J-7	L10	B-5	R31	B-3	R75	J-1	U
C13	B-6	C59	J-7	L11	B-5	R32	C-3	R76	I-2	U
C14	B-6	C60	J-2	L12	B-5	R33	B-3	R77	J-3	U
C15	B-6	C61	B-2	L13	B-5	R34	B-3	R78	B-1	U
C16	B-6	C62	D-2	L14	B-6	R35	B-2	S1	A-8	U
C17	B-7	C63	C-3	L15	B-6	R36	B-1	TP1	C-8	U
C18	B-7	C64	C-4	L16	B-6	R37	D-1	TP2	C-7	U
C19	G-7	C65	C-4	L17	B-6	R38	D-1	TP3	H-2	U
C20	G-7	C66	C-4	L18	B-6	R39	C-3	TP4	G-5	U
C21	F-7	C67	C-5	L19	B-3	R40	C-1	U1	C-3	U
C22	F-7	C68	C-5	L20	C-1	R41	B-1	U2	C-4	U
C23	B-6	C69	C-6	L21	B-7	R42	B-1	U3	C-4	U
C24	B-6	C70	C-6	L22	C-7	R43	C-7	U4	C-4	U
C25	B-3	C71	C-6	Q1	I-6	R44	C-7	U5	C-5	U
C26	B-1	C72	F-6	R1	B-3	R45	E-8	U6	C-5	U
C27	D-1	C73	I-7	R2	B-4	R46	F-8	U7	C-6	U
C28	D-1	C74	I-1	R3	B-4	R47	F-7	U8	C-6	U
C29	C-1	C75	D-8	R4	B-4	R48	F-7	U9	C-6	U
C30	B-1	C76	B-7	R5	B-4	R49	E-7	U10	D-3	U
C31	B-7	C77	B-7	R6	B-4	R50	D-8	U11	D-4	U
C32	F-8	C78	B-7	R7	B-5	R51	D-8	U12	D-4	U
C33	F-7	CR1	F-8	R8	B-5	R52	D-8	U13	D-4	U
C34	F-8	CR2	F-7	R9	B-5	R53	E-7	U14	D-5	U
C35	D-8	CR3	F-7	R10	B-5	R54	E-7	U15	D-5	U
C37	E-7	CR4	D-8	R11	B-5	R55	D-7	U16	D-6	U
C38	D-8	CR5	E-8	R12	B-6	R56	E-8	U17	D-6	U
C39	E-8	J1	A-8	R13	B-6	R57	E-8	U18	D-7	U
C40	F-7	J2	A-6	R14	B-6	R58	E-7	U19	E-3	U
C41	F-7	J3	A-5	R15	B-6	R59	E-7	U20	E-4	U
C42	F-8	J4	A-3	R16	B-6	R60	I-3	U21	E-5	U
C43	E-7	J5	E-4	R17	B-7	R61	E-7	U22	E-5	U
C44	H-7	J6	E-5	R18	B-7	R62	E-7	U23	E-6	U
C45	H-7	J7	E-6	R19	B-7	R63	E-7	U24	E-6	U
C46	H-6									

Figure 8-15. Parts Identification, Board Assembl









Figure 8-16.
Schematic 5, Data Input and Threshold
8-19





**A6**

1600A-039

Figure 8-17. Parts Identification, Board Assembly A6






Figure 8-18.
Schematic 6, Trigger Word Select
8-21/(8-22 blank)




A6 TRIGGER SWITCH ASSY



P/O A1

NOTE
See Fig. 8-15 For A1
Parts Identification









Figure 8-19.
Schematic 7, Temporary Storage and Pattern Recognition
8-23








A10

1600A-042

Figure 8-20. Parts Identification, Board Assembly A10

**DIGITAL DELAY TIMING DIAGRAM
SCHEMATIC 8**



1. Connect test equipment as shown for Operational Check Test Setup in Section V.


2. Set Model 1600A controls as follows:

CLOCK.....	
THLD	TTL
QUALIFIER Q1, Q0	OFF
SAMPLE MODE.....	REPET
START DSPL.....	ON
TRIGGER MODE	
NORM/ARM	NORM
LOCAL/BUS	LOCAL
WORD.....	ON
TRIGGER WORD.....	All Switches HI
DELAY ON/OFF	ON
DELAY Thumbwheels	00020
DISPLAY MODE	TABLE A

3. Apply waveforms shown below to clock and data inputs.

NOTE

- Unused logic not shown for A1U64, U65, U77, U81, and U87.



U67B/U84A and B* TRUTH TABLE

J	\bar{K}	Q	\bar{Q}
L	H	NO	CHANGE
L	L	L	H
H	L	H	L

* U67A and U71A/B are wired D Flip-Flops

1600A-008-01-09-75

Figure 8-21. Schematic 8, Digital Delay and Trigger Generator (Sheet 1 of 2)







Figure 8-21.
Schematic 8, Digital Delay and Trigger Generator (Sheet 2 of 2)
8-25

1600A-008-02-09-75

P/O A1 DATA ACQUISITION ASSEMBLY




DECADE COUNTERS
U70/U73-U76



PATTERN TRIG OUT
DELAYED TRIG OUT

4 87 → L
P/O XA8 P1





**TIMING GENERATOR TIMING DIAGRAM
SCHEMATIC 9**

- Set Model 1600A controls as follows.

CLOCK.....
THLD	TTL
START DSPL.....	ON
WORD.....	ON
QUALIFIER		
DSPLY/TRIG	TRIG
Q1, Q0.....	OFF
TRIGGER WORD.....	Bits 0-15 OFF

- Connect HP Model 8013B Pulse Generator OUT-PUT (+) connector to CLOCK probe and apply waveform below.



1600A-009-01-09-75

Figure 8-22. Schematic 9, Timing Generator (Sheet 1 of 2)

18 7, 10, 11






Figure 8-22.
Schematic 9, Timing Generator (Sheet 2 of 2)
8-27

Model 1600A

P/O A1 DATA ACQUISITION ASSY

2
5


PCLK




8

C32 (.01UF)
CR1

R44 (2370) → R45 (412) → +5V



16
11



+5V
R56 (1000)

17

**MEMORY WRITE TIMING DIAGRAM
SCHEMATIC 10**


Set up Model 1600A as follows:

1. Connect Test Equipment as shown for Operational Check Test Setup in Section V.
2. Set Model 1600A controls as follows.

CLOCK.....	TTL
THLD	TTL
QUALIFIER Q0/Q1	HI
DSPLY/TRIG	TRIG
SAMPLE MODE.....	REPET
TRIGGER MODE	
START DSPL.....	ON
NORM/ARM	NORM
LOCAL/BUS	LOCAL
WORK.....	ON
TRIGGER WORD.....	All Switches HI

CAUTION

A1U28 through A1U34, and A1U39 are CMOS devices which are easily damaged if contacted by static voltages.



1600A-003-01-09-75

Figure 8-23. Schematic 10, A-memory (Sheet 1 of 2)

WA3
WA2
WA1
WA0

19 11


PARTS ON THIS
SCHEMATIC

P/O A1

R64
TP5
U28-34, 46, 50,
54-57, 60, 98E
109, 110

MEMORY ADDRESS
CONTROL U54-U57

NOTE
See Fig. 8-15 For A1
Parts Identification




20 12

10

1600A-003-02-09-75

Figure 8-23.
Schematic 10, A-memory (Sheet 2 of 2)
8-29



P/O A1 DATA ACQUISITION ASSY

11 21

LWE1

TP4

GND

11 25

LWE2

WRITE ADDRESS
COUNTER
U60

7 4

11 29

11 { 22
11 { 23HDQ
CA3
CA2
CA1
CA0
LDR
HDR*

7 8

T0
T1
T2
T3
T4
T5
T6
T7
T8
T9
T10
T11
T12
T13
T14
T15

13 U29F 12

11 U29E 10

9 U29D 8

5 U29U 6

3 U29B 4

1 U29A 2

11 U31E 10

13 U31F 12

9 U31D 8

5 U31C 6

3 U31B 4

1 U31A 2

11 U33E 10


9 U33D 8

5 U33C 6

3 U33B 4

+5V

R64 1000



9 18

GND

+5V

NC

7





Figure 8-24. Schematic 11, Memory Index and Control




19
10

22
10

R → 23
10










Figure 8-25.
Schematic 12, Display Data Switch
8-31

33 6




31
20




SCHEMATIC 13

NO CLOCK Timing Diagram and Truth Table




LNCK	NO CLOCK LIGHT
0	ON
1	OFF

NO ARM Timing Diagram and Truth Table




LNARM	NO ARM LIGHT
0	ON
1	OFF

NO QUAL Timing Diagram and Truth Table



LNCK	HNQL	NO QUAL LIGHT
0	0	OFF
1	0	OFF
0	1	OFF
1	1	ON

NO TRIG Timing Diagram and Truth Table



LNCK	HNQL	HNTRG	LNARM	NO TRIG LIGHT
0	X	X	X	OFF
1	0	X	X	OFF
1	1	1	0	OFF
1	1	1	1	ON

X = Don't Care

1600A-017-01-09-75

Figure 8-26. Schematic 13, Indicator Light Control (Sheet 1 of 2)





Figure 8-26.
Schematic 13, Indicator Light Control (Sheet 2 of 2)

P/OA1 DATA ACQUISITION ASSY

NOTE
See Fig. 8-15 For A1
Parts Identification


5 1**7 4****8 9****8 10**

SCHEMATIC 14 TROUBLESHOOTING

- Set Model 1600A controls as follows:

SAMPLE MODE	SGL
DISPLAY MODE	START DSPL
WORD	ON
DELAY	OFF
COLUMN BLANKING	FULL CCW
LOGIC	POS
BYTE	4 BIT
DISPLAY MODE	TABLE A

- Monitor A1U79, A1U83 and A1U86, using Model 10528A Logic Clip. The following indications will be observed when the circuit is functioning properly.



LOGIC CLIP INDICATIONS

1600A-004-01-09-75

Figure 8-27. Schematic 14, Word Intensity (Sheet 1 of 2)

TRIGGER WORD INTENSIFY DECODING

DELAY SETTINGS	TEN'S DECADE				UNIT'S DECADE				CARRY (A1U79, PIN 14)	MULTIPLEXER 1 OUTPUT CODE		
	2D3	2D2	2D1	2D0	1D3	1D2	1D1	1D0		Za	Zc	Zd
0	1	0	0	1	1	0	0	1	1	1	1	1
1	1	0	0	1	1	0	0	0	1	1	1	1
2	1	0	0	1	0	1	1	1	1	1	1	0
3	1	0	0	1	0	1	1	0	1	1	1	0
4	1	0	0	1	0	1	0	1	1	1	0	1
5	1	0	0	1	0	1	0	0	1	1	0	1
6	1	0	0	1	0	0	1	1	1	1	0	0
7	1	0	0	1	0	0	1	0	1	1	0	0
8	1	0	0	1	0	0	0	1	1	0	1	1
9	1	0	0	1	0	0	0	0	1	0	1	1
10	1	0	0	0	1	0	0	1	1	0	1	0
11	1	0	0	0	1	0	0	0	1	0	1	0
12	1	0	0	0	0	1	1	1	1	0	0	1
13	1	0	0	0	0	1	1	0	1	0	0	1
14	1	0	0	0	0	1	0	1	1	0	0	0
15	1	0	0	0	0	1	0	0	1	0	0	0
16	1	0	0	0	0	0	1	1	1	0	X	X
17	1	0	0	0	0	0	1	0	0	0	0	0
	0	X	X	X	X	X	X	X	0	X	X	X

X = DON'T CARE





Figure 8-27.
Schematic 14, Word Intensity (Sheet 2 of 2)
8-35

P/O A1 DATA ACQUISITION ASSY




SCHEMATIC 15 TROUBLESHOOTING

- Set Model 1600A controls as follows:

SAMPLE MODE	SGL
DISPLAY MODE	TABLE A & B
TRIGGER MODE	START DSPL
WORD	ON
DELAY	OFF
THUMBWHEELS	ALL 0's
COLUMN BLANKING	FULL CCW
LOGIC	POS
BYTE	4 BIT
INTENSITY	12 O'CLOCK
FOCUS	12 O'CLOCK

- Monitor A8U32, A8U33, A8U35 with Model 10528A Logic Clip. The following indication will be observed when the circuit is functioning properly.



1600A-091-01-09-75

Figure 8-28. Schematic 15, Data Routing and Multiplexing (Sheet 1 of 2)






Figure 8-28.
Schematic 15, Data Routing and Multiplexing (Sheet 2 of 2)
8-87






A8

1600A-083-09-75

REF DESIG	GRID LOC	REF DESIG	GRID LOC
C1	J-5	R38	D-4
C2	C-5	R39	C-1
C3	J-5	R40	C-1
C4	L-5	R41	C-1
C5	L-5	R42	B-5
C6	B-2	R43	E-4
C7	C-3	R44	L-1
C8	C-1	R45	F-2
C9	D-5	R46	K-4
C10	C-5	R47	K-4
C11	C-2	R48	H-1
C12	C-4	R49	L-1
C13	E-4	R50	B-2
C14	L-5	R51	I-5
CR1	H-2	U1	B-1
CR2	I-5	U2	B-2
CR3	I-5	U3	B-3
CR5	C-1	U4	B-4
CR6	I-1	U5	B-4
L1	K-5	U6	B-5
L2	K-5	U7	C-1
P1	F-6	U8	C-2
P2	F-6	U9	C-2
P3	D-1	U10	C-3
P4	F-1	U11	C-4
P5	L-2	U12	D-1
P6	L-3	U13	D-2
P7	L-6	U14	D-3
Q1	D-4	U15	D-3
Q2	D-4	U16	D-4
Q3	K-4	U17	D-5
Q4	K-2	U18	F-1
R1	G-4	U19	F-2
R2	C-5	U20	F-3
R3	G-4	U21	F-4
R4	F-3	U22	F-4
R5	F-3	U23	F-5
R6	F-3	U24	H-1
R7	F-3	U25	G-2
R8	K-4	U26	G-2
R9	I-2	U27	G-3
R10	L-2	U28	G-3
R11	D-1	U29	G-4
R12	H-1	U30	G-4
R13	H-2	U31	I-1
R14	K-1	U32	I-2
R15	J-3	U33	I-2
R16	E-3	U34	I-3
R17	E-3	U35	I-3
R18	F-3	U36	I-4
R19	F-3	U37	I-4
R20	E-3	U38	J-1
R21	B-2	U39	J-2
R22	B-2	U40	J-3
R23	I-5	U41	J-3
R25	I-5	U42	J-2
R26	D-1	U43	K-1
R27	B-4	U44	K-2
R28	B-4	U45	K-3
R29	C-4	U46	K-3
R30	C-4	U47	K-4
R31	C-5	U48	D-1
R32	C-4	U49	L-2
R33	C-4	U50	L-3
R34	C-5	U51	B-2
R35	C-2	VR1	K-4
R36	D-4	VR2	C-5
R37	C-5	XA7	I-5

Figure 8-29. Parts Identification, Board Assembly A8








Figure 8-30.
Schematic 16, Display Counters and B-memory
8-39





SCHEMATIC 17

BLANKING TRUTH TABLE

A8U18 SELECT LINES			A8U24 SELECT LINES			A8U18 ENABLE (DSPCK*)	A8U24 ENABLE (HDSPR)	A8U24 Y OUTPUT (Blanking signal, TRUE in 0 state)
HTBD	LEXOR	LXPG1	LMAP	HSA•HTAD + HSB•HTBD	LCRCL			
X	X	X	X	X	X	X	1	0
X	X	X	0	0	0	X	0	HTWO + <u>DSPCK*</u>
X	X	X	0	0	1	X	0	HGD•HCQD•LØ
X	X	X	0	1	0	X	0	HTWO + <u>DSPCK*</u>
X	X	X	0	1	1	X	0	HGD•HCQD•LØ
X	X	X	1	0	0	X	0	0
X	X	X	1	0	1	X	0	0
X	X	X	1	1	0	X	0	0
X	X	X	1	1	1	1	0	0
0	0	0	1	1	1	0	0	A8U14, PIN 6
0	0	1	1	1	1	0	0	A8U14, PIN 6
0	1	0	1	1	1	0	0	A8U14, PIN 6
0	1	1	1	1	1	0	0	A8U14, PIN 6
1	0	0	1	1	1	0	0	LXBLK + A8U14, PIN 6
1	0	1	1	1	1	0	0	A8U14, PIN 6
1	1	0	1	1	1	0	0	LXBLK
1	1	1	1	1	1	0	0	HCBLK

1. X = Don't Care
2. A8U14, PIN 6=0 when:
 - a. HCBLK=1
 - b. HUGT•LSSS=1
 - c. HSTR•HTRG=1
 - d. LGD=1 and the qualified clock rate is greater than ≈ 30 Hz.

1600A-095-01-09-75

Figure 8-31. Schematic 17, Blanking Control (Sheet 1 of 2)







Figure 8-31.
Schematic 17, Blanking Control (Sheet 2 of 2)
8-41/(8-42 blank)









18

Figure 8-32.
Schematic 18, Data Acquisition Reset Circuitry
8-43






SCHEMATIC 19
WAVEFORM MEASUREMENT CONDITIONS

Set Model 1600A controls as follows:

SAMPLE MODE.....	SGL
DISPLAY MODE.....	TABLE A & B
TRIGGER MODE.....	START DSPL
WORD.....	ON
DELAY.....	OFF
THUMBWHEELS.....	ALL 0's
COLUMN BLANKING.....	FULL CCW
LOGIC.....	POS
BYTE.....	4 BIT
INTENSITY.....	12 O'CLOCK
FOCUS.....	12 O'CLOCK



1600A-092-01-09-75

Figure 8-33.
Schematic 19, Display Clock Generator and Display Reset (Sheet 1 of 2)






Figure 8-33.
Schematic 19, Display Clock Generator and Display Reset (Sheet 2 of 2)
8-45





SCHEMATIC 20
TRUTH TABLES

A7U7/MUX A7U8 TRUTH TABLE

INPUT		OUTPUT	
VM3	VM2	VM1	VM0
0	0	1	1
0	1	1	0
1	0	1	0
1	1	0	1

HORIZONTAL/VERTICAL DECODER TRUTH TABLE

LMAP	LXPMP	DECODER OUTPUTS
0 0 1	0 1 1	MDO-5, MD 8-13 MD2-7, MD10-15 HM1-5, VM0-5

HORIZONTAL ROM A7U14 TRUTH TABLE


INPUTS								OUTPUTS*					INPUTS								OUTPUTS*				
HTBD	HOCT	H3	H2	H1	H0	HM4	HM3	HM2	HM1	HTBD	HOCT	H3	H2	H1	H0	HM4	HM3	HM2	HM1						
0	0	0	0	0	0	1	1	1	0	1	0	0	0	0	0	1	1	1	0	1					
0	0	0	0	0	1	1	1	0	1	1	0	0	0	0	1	1	1	0	0	0					
0	0	0	0	1	0	1	1	0	0	1	0	0	0	0	1	0	1	0	1	1					
0	0	0	0	1	1	1	0	1	1	1	0	0	0	0	1	1	0	0	1	0					
0	0	0	1	0	0	1	0	0	1	1	0	0	1	0	0	1	0	0	0	0					
0	0	0	1	0	1	1	0	0	0	1	0	0	1	0	1	0	1	1	1	0					
0	0	0	1	1	0	0	1	1	1	1	0	0	1	1	0	0	1	1	0	0					
0	0	0	1	1	1	0	1	1	0	1	0	0	1	1	1	0	1	0	1	1					
0	0	1	0	0	0	0	1	0	0	1	0	0	1	0	0	0	0	1	0	1					
0	0	1	0	0	1	0	0	1	1	1	0	0	1	0	0	1	0	0	1	0					
0	0	1	0	1	0	0	0	1	1	0	0	1	0	0	1	0	0	1	0	1					
0	0	1	0	1	1	0	0	0	1	1	0	0	1	0	0	0	0	0	1	1					
0	0	1	1	0	0	1	1	1	1	1	0	0	1	1	0	0	1	1	0	0					
0	0	1	1	0	1	1	1	1	0	1	0	0	1	1	0	1	1	1	0	1					
0	0	1	1	1	0	0	1	1	0	1	0	0	1	1	1	0	1	1	0	0					
0	0	1	1	1	1	0	1	1	0	1	0	0	1	1	1	1	1	1	0	1					
0	1	0	0	0	0	1	1	1	0	0	1	0	0	0	0	1	1	1	1	1					
0	1	0	0	0	1	1	1	0	1	0	0	1	0	0	1	1	1	1	0	0					
0	1	0	0	1	0	1	1	1	0	0	0	1	0	0	1	0	1	1	0	1					
0	1	0	0	1	1	1	1	0	1	1	0	0	1	1	0	0	1	1	0	1					
0	1	0	1	0	0	1	1	0	1	0	0	1	1	0	0	1	1	1	0	1					
0	1	0	1	0	1	0	1	0	0	1	0	0	1	1	0	0	1	1	0	1					
0	1	0	1	1	0	0	1	1	0	0	1	0	0	1	1	0	0	1	1	0					
0	1	1	0	0	0	0	1	0	0	1	0	0	1	0	0	0	0	1	1	0					
0	1	1	0	0	1	0	0	0	1	0	0	1	0	0	0	1	0	0	1	1					
0	1	1	0	1	0	0	1	1	0	0	1	0	0	1	1	0	0	1	1	0					
0	1	1	1	0	0	1	1	1	0	0	1	0	0	1	1	0	0	1	1	0					
0	1	1	1	1	0	0	1	1	0	0	1	0	0	1	1	0	0	1	1	0					
0	1	1	1	1	1	0	0	1	1	0	0	1	0	0	1	1	0	0	1	1					
0	1	1	1	1	1	1	0	0	1	1	0	0	1	1	0	0	1	1	1	0					
0	1	1	1	1	1	1	1	0	0	1	1	0	0	1	1	1	0	0	1	1					
0	1	1	1	1	1	1	1	1	0	0	1	1	0	0	1	1	1	0	0	1					
0	1	1	1	1	1	1	1	1	1	0	0	1	1	1	0	0	1	1	1	0					
0	1	1	1	1	1	1	1	1	1	1	0	0	1	1	1	1	0	0	1	1					
0	1	1	1	1	1	1	1	1	1	1	1	0	0	1	1	1	1	0	0	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	0	0	1	1	1	1	0	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	1	1	1	1	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	1	1	1	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	1	1	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	1	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	1					
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1					

*HM5 IS GENERATED BY COMPARATOR A7U13.

HM5=1 IF HORIZONTAL COUNT < 10112
HM5=0 IF HORIZONTAL COUNT > 10112

1600A-021-01-09-75

Figure 8-35. Schematic 20, Horizontal and Vertical Decoders and D/A Converters (Sheet 1 of 2)




A7

1600A-040

REF E SIG	GRID LOC	REF DESIG	GRID LOC								
11	C-6	R27	J-5	R44	M-4	R61	K-4	R78	N-5	U8	H-4
12	E-6	R28	J-4	R45	M-4	R62	K-4	R79	N-6	U9	C-4
13	D-6	R29	J-5	R46	M-3	R63	K-4	R80	N-5	U10	D-4
14	E-6	R30	J-4	R47	M-3	R64	K-5	R81	N-5	U11	E-4
15	E-6	R31	J-5	R48	M-4	R65	L-6	R82	K-5	U12	F-4
16	K-4	R32	H-6	R49	N-4	R66	L-6	R83	K-5	U13	G-4
17	K-4	R33	H-6	R50	N-4	R67	M-6	R84*	H-5	U14	H-5
18	I-4	R34	H-6	R51	N-4	R68	M-5	R85	H-5	U15	D-6
19	I-4	R35	J-6	R52	O-3	R69	M-5	R86	K-5	U16	F-6
20	J-5	R36	L-4	R53	N-4	R70	M-6	S1	B-4	U17	G-6
21	H-6	R37	L-3	R54	N-4	R71	M-5	U1	C-3	U18	J-4
22	I-5	R38	L-3	R55	M-3	R72	N-5	U2	D-3	U19	L-5
23	I-6	R39*	L-3	R56	N-4	R73	N-5	U3	D-3	U20	M-4
24	I-6	R40	L-3	R57	N-4	R74	N-4	U4	E-3	U21	M-5
25	J-5	R41	L-4	R58	N-4	R75	N-6	U5	F-3	U22	C-3
26	J-5	R42	L-4	R59	N-4	R76	N-5	U6	G-3	VR1	K-3
		R43	L-4	R60	N-4	R77	N-5	U7	H-4	VR2	K-4

Parts Identification, Board Assy A7



REF DESIG	GRID LOC								
C1	B-6	C17	L-4	CR4	K-4	Q13	N-5	R11	C-6
C2	C-6	C18	O-3	L1	I-4	Q14	O-3	R12	E-6
C3	C-6	C19	N-4	P1	K-2	Q15	O-4	R13	D-6
C4	D-6	C20	M-3	P2	O-4	Q16	O-5	R14	E-6
C5	E-6	C21	M-6	Q1	I-4	Q17	O-5	R15	E-6
C6	E-6	C22	M-4	Q2	I-5	Q18	K-6	R16	K-4
C7	I-5	C23	L-5	Q3	I-5	R1	K-6	R17	K-4
C8	I-5	C24	M-5	Q4	J-6	R2	G-4	R18	I-4
C9	J-5	C25	L-5	Q5	K-5	R3	G-5	R19	I-4
C10	J-5	C26	O-4	Q6	K-4	R4	G-5	R20	J-5
C11	J-5	C27	N-6	Q7	L-4	R5	G-5	R21	H-6
C12	K-5	C28	K-3	Q8	M-3	R6	G-5	R22	I-5
C13	M-4	C29	K-4	Q9	N-3	R7	G-3	R23	I-6
C14	M-3	CR1	D-5	Q10	N-4	R8	C-6	R24	I-6
C15	L-4	CR2	F-5	Q11	N-5	R9	B-6	R25	J-5
C16	M-4	CR3	K-5	Q12	N-5	R10	C-6	R26	J-5

Figure 8-34. Parts Ide





Figure 8-35.
Schematic 20, Horizontal and Vertical Decoders and
D/A Converters (Sheet 2 of 2)

31 12




83 21

VERTICAL D/A
CONVERTER
U15

HORIZONTAL D/A
CONVERTER
U16

84 21








Figure 8-36. Schematic 21. Analog Output Amplifiers (Sheet 1 of 2)

SCHEMATIC 21
WAVEFORM MEASUREMENT CONDITIONS

Set Model 1600A controls as follows:


SAMPLE MODE.....	SGL
DISPLAY MODE.....	TABLE A & B
TRIGGER MODE.....	START DSPL
WORD.....	ON
DELAY.....	OFF
THUMBWHEELS.....	ALL 0's
COLUMN BLANKING.....	FULL CCW
LOGIC.....	POS
BYTE.....	4 BIT
INTENSITY.....	12 O'CLOCK
FOCUS.....	12 O'CLOCK






21

Figure 8-36.
Schematic 21. Analog Output Amplifiers (Sheet 2 of 2)





J6 INTERCONNECTION TABLE

A8P5 PIN NO.	A8P6 PIN NO.	SIGNAL
5		GND
2		50 KHZ CLK
15		LXPG3
12		LWEX
10		Lwdx
6	6	XH0
5	5	XH1
	4	XH2
	3	XH3
12	12	XV0
9	9	XV1
10	10	XV2
8	8	XV3
14		XDSPD
13		HGDX
15	15	LXMR
13	13	HXRPR
14	14	HMRXT
3		HBRXT
1		LXDPR
6	6	LXBNK
7	7	HBCDX
1	1	EDTBS
8		LXPG1
16	2	LXPG2
11,16		+5V
		L1600(GND)
		SHIELD (GND)






Figure 8-37. Schematic 22, I/O Port J6

J6 INT


J6 PIN NO.	A8P5 PIN NO.
1	5
2	2
3	15
4	12
5	10
6	
7	
8	
9	
10	
11	
12	
13	
14	14
15	13
16	
17	
18	
19	3
20	1
21	6
22	
23	
24	8
25	16
33	
35	
36	




**1820-0069
1820-0071
1820-0588
1820-0697**




**1820-0070
1820-0589**




1820-0077




1820-0382




1820-0515



1820-0584






1820-0640




1600A-085-01-09-75

Figure 8-38.
Integrated Circuit Identification (Sheet 1 of 2)
8-51








1820-0054
1820-0583
1820-0585
1820-0681




1820-0068
1820-0587
1820-0685
1820-0686




1820-0231
1820-0778
1820-1475




1820-0669
1820-1373




1820-0321







1820-0596
1820-0693








1820-0629









**1820-0054
1820-0583
1820-0585
1820-0681**



**1820-0596
1820-0693**

Model 1600A





















Figure 8-38. Integrated Circuit Identification (Sheet 2 of 2)

1600A-085-02-09-75



Figure







51

1820-0687



1820-0691

1820-0692




1820-1146


1820-1139



1820-1106




1820-1340




FUNCTION TABLE		
INPUTS		OUTPUTS
SELECT	STROBE	
B A	S	Y W
X X	H	L H
L L		D0 D0
L H	L	D1 D1
H L	L	D2 D2
H H	L	D3 D3
L L	L	D4 D4
L H	L	D5 D5
H L	L	D6 D6
H H	L	D7 D7


DATA
SELECT
(BINARY)
A →
B →
C →



1820-0661





1820-0687




INPUT		WHEN CO = L	WHEN CO = H
		WHEN C2 = L	WHEN C2 = H
A1	B1 A2 B2	z1 z2	z1 z2
A3	B3 A4 B4	z3 z4	z3 z4
		C4	C4
L L	L L	L L	L L
H L	L L	H L	L L
L H	L L	H L	L H
H H	L L	H L	H L
L L	H L	L H	H L
H L	H L	H H	L L
L H	H L	H H	L L
H H	L L	H L	H L
L L	H L	L H	H L
H L	H H	H L	H H
L H	H H	H L	H H
H H	H H	H H	H H

H = HIGH LEVEL, L = LOW LEVEL


NOTE: INPUT CONDITIONS AT A3, A2, B2, AND C0 ARE USED TO DETERMINE OUTPUTS z1 AND z2, AND THE VALUE OF THE INTERNAL CARRY C2. THE VALUES AT C2, A3, B3, A4, AND B4 ARE THEN USED TO DETERMINE OUTPUTS z3, z4, AND C4.




1820-0981




1820-1



1820-1106








FUNCTION TABLE

INPUTS	OUTPUTS		
SELECT	STROBE	Y	W
X X X	H	L	H
L L L	L	D0	D0
L L H	L	D1	D1
L H L	L	D2	D2
L H H	L	D3	D3
H L L	L	D4	D4
H H L	L	D5	D5
H H H	L	D6	D6
		D7	D7

DATA SELECT (BINARY): A → \bar{A} , B → \bar{B} , C → \bar{C}




1820-1217





FUNCTION TABLE

INPUT	WHEN CO = L	WHEN C2 = L	WHEN C2 = H	
A1 A3	B1 B3	B2 B4	C1 C3	C2 C4
L L	L L	L L	L	H L L
H L	L L	H L	L	L H L
L H	L L	H L	L	L H L
H H	L L	L H	L	H H L
L L	H L	L H	L	H H L
H L	H L	H H	L	L L H
L H	H L	H H	L	L L H
H H	L L	H L	H	H L H
L L	H L	H L	H	L H I
H L	L H	H H	L	L L H
L H	L H	H H	L	L L H
H H	L H	H L	H	H L H
L L	H H	H L	H	L H L
H L	H H	H L	H	I H H
L H	H H	L H	H	L H H
H H	H H	L H	H	H H H

1820-0981



1820-0910





SALES & SERVICE OFFICES

UNITED STATES

ALABAMA 8290 Whitesburg Dr., S.E. P.O. Box 4207 Huntsville 35802 Tel: (205) 881-4591 TWX: 810-726-2204 Medical Only 228 W. Valley Ave.. Room 302 Birmingham 35209 Tel: (205) 879-2081/2	9606 Aero Drive P.O. Box 23333 San Diego 92123 Tel: (714) 279-3200 TWX: 910-335-2000 Calculators Only 601 California St., San Francisco 94108 Tel: (415) 989-8470	ILLINOIS 5500 Howard Street Skokie 60076 Tel: (312) 677-0400 TWX: 910-223-3613 St. Joseph Tel: (217) 469-2133	MASSACHUSETTS 32 Hartwell Ave. Lexington 02173 Tel: (617) 861-8960 TWX: 710-326-6904	MICHIGAN 23855 Research Drive Farmington 48242 Tel: (313) 476-6400 TWX: 810-242-2900	MINNESOTA 2400 N. Prior Ave. Roseville 55113 Tel: (612) 636-0700 TWX: 910-563-3734	NEW YORK 6 Automation Lane Computer Park Albany 12205 Tel: (518) 456-1550 TWX: 710-441-8270	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	P.O. Box 27409 6300 Westpark Drive Suite 100 Houston 77027 Tel: (713) 781-6000 TWX: 910-881-2645
ARIZONA 2336 E. Magnolia St. Phoenix 85034 Tel: (602) 224-1361 TWX: 910-951-1331 2424 East Aragon Rd. Tucson 85706 Tel: (602) 889-4661	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	INDIANA 7301 North Shadeland Ave. Indianapolis 46250 Tel: (317) 842-1000 TWX: 810-260-1795	MASSACHUSETTS 32 Hartwell Ave. Lexington 02173 Tel: (617) 861-8960 TWX: 710-326-6904	MISSOURI 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	MINNESOTA 2400 N. Prior Ave. Roseville 55113 Tel: (612) 636-0700 TWX: 910-563-3734	NEW YORK 6 Automation Lane Computer Park Albany 12205 Tel: (518) 456-1550 TWX: 710-441-8270	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	UTAH 2160 South 3720 West Street Salt Lake City 84119 Tel: (801) 487-0715
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	CONNECTICUT 12 Linal Drive New Haven 06525 Tel: (203) 389-6551 TWX: 710-465-2029	KANSAS Derby Tel: (316) 267-3655	MISSISSIPPI Jackson Medical Service only Tel: (601) 982-9363	MISSOURI 11131 Colorado Ave. Kansas City 64137 Tel: (816) 763-8000 TWX: 910-771-2087	MISSISSIPPI Jackson Medical Service only Tel: (601) 982-9363	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
ARKANSAS Medical Service Only Little Rock 72205 Tel: (501) 664-8773	FLORIDA P.O. Box 24210 2806 W. Oaklane Park Blvd. Fort Lauderdale 33307 Tel: (305) 731-2020	LOUISIANA P.O. Box 840 3239 Williams Boulevard Kenner 70062	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	NEW YORK Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000	OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-630-6862	PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401
CALIFORNIA 1430 East Orange Grove Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288	5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 TWX: 910-935-0705	LOUISIANA P.O. Box 3307 Orlando 32801 Tel: (305) 855-4099	KANSAS Derby Tel: (316) 267-3655	KANSAS 1902 Broadway Iowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467	KANSAS 1902 Broadway Iowa City 52240 Tel: (3			

HEWLETT  PACKARD

01600-90903

PRINTED IN U.S.A.

OPERATING NOTE/AUGUST 1974




Figure 1. Model 10231B Six Bit Data Probe

1. INTRODUCTION.

2. This operating note provides operating and service information for the Hewlett-Packard Model 10231B Six Bit Data Probe (figure 1).

3. DESCRIPTION.

4. The Model 10231B is an active probe providing six channels of TTL(transistor-transistor logic) digital data to a Logic Analyzer (i.e., Hewlett-Packard Model 1601A Logic State Analyzer or Hewlett-Packard Model 1620A Pattern Analyzer) without significant loading of the circuitry under test. Minimal loading is maintained by placing active circuitry in a compact pod located near the point of test. Signal shaping and amplification is accomplished by comparators in series with each input. Probe operating power is supplied by the logic analyzer through the interconnecting cable. The Model 10231B connects to a logic-analyzer front panel by means of a 17-pin miniature snap-in connector. Refer to table 1 for complete specifications and instrument compatibility for the Model 10231B.

Table 1. Specifications

PROBE INPUTS

INPUT RC: $40 \pm 3\text{K}\Omega$ shunted by $\leq 14 \text{ pF}$.
INPUT BIAS CURRENT: $\leq 20 \mu\text{A}$.

INPUT THRESHOLD: TTL, fixed at $+1.45 \pm 0.05 \text{ Vdc}$. Variable to $\pm 10 \text{ Vdc}$.

MINIMUM INPUT SWING: $0.5\text{V p-p} \pm 5\%$ of threshold voltage.

MAXIMUM INPUT: Level, $\pm 15 \text{ Vdc}$ max.
Swing, 15V peak from threshold.

INSTRUMENT COMPATIBILITY

HP Model 1601A, Logic State Analyzer.
HP Model 1620A, Pattern Analyzer.

5. CLAIMS.

6. Upon receipt, inspect the instrument for damage and if none is noted, accomplish the performance

10231-90903



For more information, call the local HP Sales Office or East (201) 265-5000 . Midwest (312) 677-0400 . South (404) 436-6181 West (213) 877-1282. Or, write: Hewlett-Packard, 1501 Page Mill Road, Palo Alto, California 94304. In Europe, Cable "HEWPACKSA" Tel (022) 41.54.00 or write Hewlett-Packard, 1217 Meyrin-Geneva, Switzerland.

checks. Hewlett-Packard Company guarantees the performance of the instrument as stated in the certification located near the back of this note. If the physical or operating conditions of the instrument are unsatisfactory, notify the carrier and the nearest HP Sales/Service Office immediately. HP will arrange for repair or replacement without waiting for settlement of the claim by the carrier.

7. ACCESSORIES.

8. The Model 10231B is supplied with six 12-inch color coded connection leads, six detachable hook-type circuit probes, ground lead and a vinyl carrying case. Each connecting lead has a 6 x 32 screw tip on the end which attaches to the comparator pod, and a 0.025-inch female square-pin tip on the other end for backplane pin connections. The hook-type circuit probes have recessed male pins which can be attached to the connecting lead ends. The ground lead has a nondetachable alligator clip which will support the weight of the circuit pod. In addition, labels designating Bit 6 through Bit 11, and Bit 12 through Bit 15, SER QUAL and SER DATA are supplied for use with two additional data probes. Vinyl carrying cases with handles and space to carry three probes or four probes are also available (HP Part No. 1540-0250 for three probes, HP Part No. 1540-0325 for four probes).

9. PRINCIPLES OF OPERATION.

10. The Model 10231B circuitry consists of a -6.2-volt supply, six identical comparators, and six inverting line drivers which buffer, amplify, and convert input data to a TTL compatible output (see figure 3).

11. The -6.2-volt supply consists of R19, VR1, C17, C18, C19. R19 and VR1 form a voltage divider and regulator which reduces the -12-volt input to -6.2 volts. C17, C18 and C19 bypass line variations to ground.

12. The Model 10231B accepts positive or negative input data up to 15 volts peak in amplitude with threshold levels up to ± 10 Vdc.

13. U8 and U9 are resistor networks which form voltage dividers at the data inputs to each comparator. The 26.1 kilohm and 13 kilohm resistors form voltage dividers which scale input data voltage swings to levels compatible with the comparator inputs. The reference threshold voltage supplied by the Logic Analyzer has also been scaled by a factor of three. For example, the threshold for transistor-

transistor logic is typically +1.5 Vdc. The reference TTL threshold supplied by the Logic Analyzer is approximately +0.5 Vdc. The 8.68 kilohm resistor on the threshold input line matches the threshold input impedance of the comparator to the data input impedance.

14. In the static condition, the outputs of comparators U1 through U6 are LO (approximately +0.5 Vdc). When the input data voltage level exceeds the threshold level, the output will go HI (approximately +3V). The comparator outputs are inverted by U7A through U7F and applied to the logic analyzer.

15. Each comparator has positive feedback through two 1-megohm resistors which form a hysteresis band preventing comparator oscillation if the data input voltage level occurs at the exact threshold of the comparator.

16. MAINTENANCE.

17. PERFORMANCE TESTS.

18. The Model 10231B must be tested as part of the logic analyzer that the probe is supplied with. Refer to the following performance tests in Section V of the logic analyzer operating and service manual.

Input Threshold	Input RC
Input Logic Swing	Input Bias Current

19. REPAIR.

20. When repairing A1, be careful to prevent breakage of small wires where W1 is soldered to A1.

21. REPLACEABLE PARTS.

22. Table 2 lists the replaceable parts and identifies the Hewlett-Packard part number of each item. Figure 2 shows the location of each component. Figure 4 is an exploded view of the Model 10231B.

23. To order a replaceable part from Hewlett-Packard, address the order to the nearest HP Sales/Service Office. Include the probe model number, the serial number, the reference designation of the part, and the HP Part number. If a part is not listed, provide a description of the part, including function and location.

24. Board assembly A1 is not sold separately. To obtain a replacement assembly, the entire probe unit must be ordered. Order HP Model 10231B.

UNIVERSITEIT VAN AMSTERDAM
Electronic Support Group

Valckenierstraat 65
1018 XE Amsterdam

NOTE: PIN 14 OF U7 IS CONNECTED
TO GND THROUGH A .47 UF
CAPACITOR AS SHOWN BELOW.







Figure 3.
Model 10231B Schematic
Page 3





REF DESIG	GRID LOC	REF DESIG	GRID LOC
C1	D-3	L5	A-2
C2	D-3	L6	A-1
C3	C-3	R1	D-3
C4	D-3	R2	D-2
C5	C-3	R3	D-2
C6	C-3	R4	C-3
C7	C-1	R5	C-2
C8	D-1	R6	C-2
C9	C-1	R7	B-2
C10	C-1	R8	B-2
C11	D-1	R9	C-2
C12	D-1	R10	C-1
C13	D-3	R11	C-2
C14	D-3	R12	C-2
C15	C-2	R13	B-1
C16	D-1	R14	C-2
C17	D-1	R15	B-2
C18	B-2	R16	D-1
C19	D-2	R17	D-2
C20	E-3	R18	D-2
E1	A-3	R19	E-1
E2	A-3	U1	D-2
E3	A-2	U2	C-2
E4	A-2	U3	C-2
E5	A-2	U4	C-2
E6	A-1	U5	C-2
E7	A-1	U6	D-2
L1	A-3	U7	E-2
L2	A-3	U8	C-2
L3	A-2	U9	C-1
L4	A-2	VR1	D-1

Figure 2. Model 10231B Component Identification

Table 2. Replaceable Parts (Cont'd)

Reference Designation	HP Part No.	Qty	Description	Mfr. Code	Mfr. Part No.
A1R7	0675-1021		R: Fxd 1 K 10% .125 W CC Tubular	01121	BB 1021
A1R8	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R9	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R10	0675-1021		R: Fxd 1K 10% .125 W CC Tubular	01121	BB 1021
A1R11	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R12	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R13	0675-1021		R: Fxd 1 K 10% .125 W CC Tubular	01121	BB 1021
A1R14	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R15	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R16	0675-1021		R: Fxd 1 K 10% .125 W CC Tubular	01121	BB 1021
A1R17	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R18	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R19	0698-3698	1	R: Fxd 47 5% 1W Mo Tubular	16299	FP32-1-T0047R0-J
A1U1 Thru A1U6	1826-0236	6	IC: DGTL, Comparator	18324	UA760
A1U7	1820-0683	1	IC: DGTL, Inverter	01295	SN74S04N
A1U8	1810-0211	2	CIRCUIT: PSIV, Non-Rprable In	28480	1810-0211
A1U9	1810-0211		CIRCUIT: PSIV, Non-Rprable In	28480	1810-0211
A1VR1	1902-0551	1	DIODE: Zener 6.19 V VZ, 1W Max Pd	04713	SZ 11213-80

Table 2. Replaceable Parts

Reference Designation	HP Part No.	Qty	Description	Mfr. Code	Mfr. Part No.
CP1 Thru CP6	10230-62101	7	PROBE ASSY: Circuit	28480	10230-62101
MP1	5040-7683	1	COVER: Top	28480	5040-7683
MP2	5040-7685	1	COVER: Bottom	28480	5040-7685
MP3	7120-4389	1	LABEL: Ident	28480	7120-4389
MP4	7120-4383	1	LABEL SET: Ident, Orange	28480	7120-4383
MP5	7120-4388	1	LABEL SET: Ident, Green	28480	7120-4388
MP6	1540-0251	1	CASE: Carrying	28480	1540-0251
W1	10231-61601	1	CABLE ASSY: 17 Pin	28480	10231-61601
W2	10231-61608	1	CABLE: Pin Adapter; White/Black	28480	10231-61608
W3	10231-61612	1	CABLE: Pin Adapter; White/Brown	28480	10231-61612
W4	10231-61613	1	CABLE: Pin Adapter; White/Red	28480	10231-61613
W5	10231-61614	1	CABLE: Pin Adapter; White/Orange	28480	10231-61614
W6	10231-61615	1	CABLE: Pin Adapter; White/Yellow	28480	10231-61615
W7	10231-61616	1	CABLE: Pin Adapter; White/Green	28480	10231-61616
W8	10231-61611		CABLE: Ground	28480	10231-61611
A1C1 Thru A1C12	0160-3592	12	C: Fxd Cer 2.4 pF ±.5 pF 200 Vdcw	28480	0160-3592
A1C13	0160-0174	2	C: Fxd Cer 0.47 µF +0 —20% 25 Vdcw	56289	5C1187S-CML
A1C14 Thru A1C19	0160-3451	6	C: Fxd Cer 0.47 µF +80 —20% 100 Vdcw	56289	C0238101F103ZS25-CD
A1C20	0160-0174		C: Fxd Cer 0.01 µF +80 —20% 25 Vdcw	56289	561187S-CML
A1E1 Thru A1E6	10230-25701	6	NUT: Cable Connector	28480	10230-25701
A1E7	10230-25702	1	INSERT: Threaded	28480	10230-25702
A1L1 Thru A1L6	9170-0029	6	CORE: Ferrite Bead	02114	56-590-65A2/4A
A1R1	0675-1021	6	R: Fxd 1 K 10% .125 W CC Tubular	01121	BB 1021
A1R2	0698-4073	12	R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R3	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R4	0675-1021		R: Fxd 1 K 10% .125 W CC Tubular	01121	BB 1021
A1R5	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051
A1R6	0698-4073		R: Fxd 1 M 10% .125 W CC Tubular	01121	BB 1051




Figure 4. Model 10231B Exploded View

CERTIFICATION

The Hewlett-Packard Company certifies that this instrument was thoroughly tested and inspected and found to meet its published specifications when it was shipped from the factory. The Hewlett-Packard Company further certifies that its calibration measurements are traceable to the U.S. National Bureau of Standards to the extent allowed by the Bureau's calibration facility.

WARRANTY AND ASSISTANCE

This Hewlett-Packard product is warranted against defects in materials and workmanship. This warranty applies for one year from the date of delivery, or, in the case of certain major components listed in the operating manual, for the specified period. We will repair or replace products which prove to be defective during the warranty period provided they are returned to Hewlett-Packard. No other warranty is expressed or implied. We are not liable for consequential damages.

Service contracts or customer assistance agreements are available for Hewlett-Packard products that require maintenance and repair on-site.



MANUAL CHANGES

MODEL 1600A
LOGIC STATE ANALYZER

Manual Serials Prefixed: 1533A
Manual Printed: SEPT 1975

Make all changes listed below as Errata. Check the following table for your instrument serial prefix and/or serial number and make listed change(s) to the manual:

Serial Prefix or Number	Make Changes	Serial Prefix or Number	Make Changes

△ ERRATA

- Page 5-4, paragraph 5-14,
Step e: Revise CLOCK setting i.e., neg. slope.
Delete: Step k.
- Page 5-4, figure 5-4,
Show all data probes and the clock probe connected directly to the function generator.
Show monitor oscilloscope connected to function generator through a 10:1 probe.
- Page 5-7, paragraph 5-18,
 $50\Omega \pm 2\Omega$: Change to read $50\Omega \pm 2.5\Omega$ in step b.
- Page 5-9, figure 5-10,
(LWE WIDTH): Change to read (HDL TRAILING EDGE).
(HDL TRAILING EDGE): Change to read (LWE WIDTH).
- Page 5-10, paragraph 5-24,
A1C37: Change to read A1C41 in step k.
A1C41: Change to A1C37 in step l.
- Page 6-3, figure 6-1,
Add: MP58 to component shown below MP7.
Add: MP59, screw, to hold on top and bottom instrument covers.
Add: MP60 to screw holding pouch on top cover.
- Page 6-4, figure 6-1,
Add: MP57, shield, sheet metal, attaching to MP38 and shields T1.
- Table 6-2,
F1: Add to description STANDARD.
Add: F1, HP Part No. 2110-0016, FUSE 0.6A 250V SLO-BLO (OPTIONS 900-902, 906), Mfr Code 71400, Mfr Part No. MDL-6/10.
- J4: Change to HP Part No. 1250-0659, CONNECTOR- RF TPS FEM SGL-HOLE-FR 50-OHM, Mfr Code 24931, Mfr Part No. 23JR107-1.
- Table 6-2 (Cont'd),
J6: Add to description PART OF W5.
MP31: Add to description PART OF W6.
Delete: MP32.
MP33: Change HP Part No. and Mfr Part No. to 01600-24701.
MP47: Change HP Part No. and Mfr Part No. to 01600-60602.
MP54: Change HP Part No. and Mfr Part No. to 175A-91.
Add: MP57, HP Part No. 01600-00601, SHIELD:TRANSFORMER, Mfr Code 28480, Mfr Part No. 01600-00601.
Add: MP58, HP Part No. 01600-01206, BRACKET:PC HOLDON, Mfr Code 28480, Mfr Part No. 01600-01206.
Add: MP59, HP Part No. 2200-0762, SCREW, MACH 4-40 BLACK, Mfr Code 28480, Mfr Part No. 2200-0762.
Add: MP60, HP Part No. 2360-0197, SCREW, 6-32 X .375, Mfr Code 28480, Mfr Part No. 2360-0197.
Add: Q3, HP Part No. 1854-0433, TRANSISTOR NPN SI PD=90W FT=2MHZ, Mfr Code 28480, Mfr Part No. 1854-0433.
Add: W17 HP Part No. 01600-61602, CABLE, POWER LIGHT AND THRESHOLD SWITCH, Mfr Code 28480, Mfr Part No. 01600-61602.
XV1: Add to Description PART OF W6.
A1C53: Change to HP Part No. 0160-3447, CAPACITOR-FXD 470 PF +10% 1000WVDC, Mfr Code 28480, Mfr Part No. 0160-3447.
A1J1: Delete HP and Mfr Part No. Change description to CONSISTS OF A1J1E1, A1J1MP1, AND A1J1MP2.
Add: A1J1E1, HP Part No. 1251-0699, CONNECTOR: MALE 17-PIN, Mfr Code 4H713, Mfr Part No. 280-50-00-002.
Add: A1J1MP1, HP Part No. 5040-7478, HOUSING:TOP CONNECTOR, Mfr Code 28480, Mfr Part No. 5040-7478.

June 14 1976

△ = Latest additions to this change sheet.

This change sheet supersedes all prior change sheets for this manual.

Supplement A for
01600-90903

△ ERRATA (CONT'D)

Table 6-2 (Cont'd),

Add: A1J1MP2, HP Part No. 5040-7479, HOUSING: BOTTOM CONNECTOR, Mfr Code 28480, Mfr Part No. 5040-7479.

A1J2: Delete HP and Mfr Part Nos. Change description to CONSISTS OF A1J1E1, A1J1MP1, AND A1J1MP2.

A1J3: Delete HP and Mfr Part Nos. Change description to CONSISTS OF A1J1E1, A1J1MP1, AND A1J1MP2.

A1J4: Delete HP and Mfr Part Nos. Change description to CONSISTS OF A1J1E1, A1J1MP1, AND A1J1MP2.

A1J5 through A1J9: Change to HP Part No. 1200-0474, SOCKET, ELECT, IC 14-CONT DIP SLDL TERM, Mfr Code 06776, Mfr Part No. ICN-143-S3.

Delete: A1MP1 and A1MP2.

A1R28: Change to HP Part No. 0757-0401, RESISTOR 100 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-101-F.

A1R29: Change to HP Part No. 0757-0407, RESISTOR, 200 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-201-F.

A1R77: Change to HP Part No. 0684-4711, RESISTOR 470 10% .25W CC, Mfr Code 01121, Mfr Part No. CB4711.

Add: A1R78, HP Part No. 0757-0457, RESISTOR 47.5K 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-4752-F.

A2R20: Change to HP Part No. 0684-4711, RESISTOR 470 10% .25W CC TC=0+529, Mfr Code 01121, Mfr Part No. CB4711.

A3C1: Change to HP Part No. 0180-0484, CAPACITOR-FXD; 250 UF +50-10% 200VDC AL, Mfr Code 56289, Mfr Part No. 36D251F200AA2A-DQB.

A3C5: Change to HP Part No. 0180-0484, CAPACITOR-FXD 4500 UF +75-10% 25VDC AL, Mfr Code 56289, Mfr Part No. 36D452G025AA-2B-DQB.

A3MP4: Add to Description NOT SUPPLIED WITH A3, ORDER SEPARATELY.

Add: A6S1, HP Part No. 3101-0576, SWITCH-TGL SUBMIN SPDT NS 2A 250VAC, Mfr Code 28480, Mfr Part No. 3101-0576.

A7C11: Change to HP Part No. 0140-0231, CAPACITOR-FXD 440 PF +-1% 300WVDC MICA, Mfr Code 72136, Mfr Part No. DM15F441FO300WV1C.

Delete: A7CR3 and A7CR4.

A7Q5: Change to HP Part No. 1854-0071, TRANSISTOR NPN SI PD=300MW FT= 200 MHZ, Mfr Code 28480, Mfr Part No. 1854-0071.

A7Q18: Change to HP Part No. 1854-0071, TRANSISTOR NPN SI PD=300MW FT=200 MHZ, Mfr Code 28480, Mfr Part No. 1854-0071.

A7R1: Change to HP Part No. 0757-0441, RESISTOR 8.25K 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-8251-F.

Table 6-2 (Cont'd),

A7R32: Change to HP Part No. 0675-6811, RESISTOR 680 10% .125W CC, Mfr Code 01121, Mfr Part No. BB6811.

A7R33: Change to HP Part No. 0757-0443, RESISTOR 11K 1% .125W F TC=0+-100 Mfr Code 24546, Mfr Part No. C4-1/8-T0-1102-F.

A7R34: Change to HP Part No. 0757-0441, RESISTOR 8.25K 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-8251-F.

A7R35: Change to HP Part No. 0684-4731, RESISTOR 47K 10% .25W FC TC=-400/+800, Mfr Code 01121, Mfr Part No. CB4731.

A7R36: Change to HP Part No. 0757-0442, RESISTOR 10K 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-1002-F.

A7R61: Change to HP Part No. 0757-0920, RESISTOR 680 2% .125W F TUBULAR, Mfr Code 24546, Mfr Part No. C4-1/8-T0-681-G.

A7R62: Change to HP Part No. 0757-0441, RESISTOR 8.25K 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-8251-F.

A7R64: Change to HP Part No. 0684-4731, RESISTOR 47K 10% .25W FC TC=-400/+800, Mfr Code 01121, Mfr Part No. CB4731.

A7R82: Change to HP Part No. 0757-0920, RESISTOR 680 2% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-681-G.

A7R86: Change to HP Part No. 0684-4731, RESISTOR 47K 10% .25W FC TC=-400/+800, Mfr Code 01121, Mfr Part No. CB4731.

A7R87: Change to HP Part No. 0698-7096, RESISTOR 10 10% .125W CC TC=0+588, Mfr Code 01121, Mfr Part No. BB1001.

A7R88: Change to HP Part No. 0698-7096, RESISTOR 10 10% .125W CC TC=0+588, Mfr Code 01121, Mfr Part No. BB1001.

A7R89: Change to HP Part No. 0757-0442, RESISTOR 10K 1% .125W F TC=0+-100, Mfr Code 24546, Mfr Part No. C4-1/8-T0-1002-F.

A7VR2: Change to HP Part No. 1902-3114, DIODE-ZNR 6.19V 5% PD=.4W, Mfr Code 04713, Mfr Part No. SZ10939-123.

A8R48: Change to HP Part No. 0684-1021, RESISTOR 1K 10% .25W FC TC=-400/+600, Mfr Code 01121, Mfr Part No. CB1021.

Delete: A8R49.

Add: A8R52, HP Part No. 0684-1011, RESISTOR 100 10% .25W FC TC=-400/+500, Mfr Code 01121, Mfr Part No. CB1011.

Add: A8R53, HP Part No. 0757-0448, RESISTOR 18.2K 1% .125W F, Mfr Code 24546, Mfr Part No. C4-1/8-T0-1822-F.

△ ERRATA (CONT'D)

- Schematic 1,
Add: W17 to designate wires from A1 to R1, DS6, and TP1.
- Page 8-10, figure 8-9,
R1: Change reference designator to R2.
R2: Change reference designator to R1.
- Schematic 2,
A3R2: Change value to 220K.
A3R6: Change value to 100K.
A3R13: Change value to 1780.
- Schematic 3,
R8: Change wire color (8) to read (2).
A2R27: Change +110V connection to +12V.
A2R31: Maintain connection to +110V.
V1: Change wire colors as follows: (945) to read (934), (934) to read (93), 9 to read (5), 8 to read (945).
REAR VIEW NECK PIN CONNECTIONS: Change wire colors as follows: (945) to read (934), and (934) to read (945).
- Schematic 4,
A7U22: Show all resistor values as 6000 ohms.
A4U3: Show all resistor values as 6000 ohms.
A5U3: Show all resistor values as 6000 ohms.
- Schematic 5,
Add: W17 designation to wires to TP1, R1, R10, and DS6.
- Schematic 7,
A1R28: Change value to 100.
A1R29: Change value to 200.
- Schematic 9,
A1L22: Change value to 1.5.
- Schematic 11,
A1C53: Change value to 470.
- Schematic 15,
A8U31A: Pin 5 change number to 4, and pin 4 change number to 5.
- Page 8-38, figure 8-29,
R50: Change reference designator to R51.
R51: Change reference designator to R50.
- Schematic 16,
A8U37 pins 10 and 11: Change associated reference designator to U37E.
A8U49: Add value of 6000 ohms to all four associated resistors.
- Schematic 17,
A8U14: Change pin 13 to read 12 and change pin 12 to read 13.
A8U18: Change notation A to read C and change notation C to read A.
A8U24: Change notation A to read C and change notation C to read A.
- Schematic 18,
A8R28: Change grounded side to be connected to +5V.
- Schematic 19,
Signal 78: Show destination schematics of 16, 17, and 18.
- Page 8-46, figure 8-34,
R62: Change reference designator to R63.
R63: Change reference designator to R62.
- Page 8-46, HORIZONTAL ROM A7U14 TRUTH TABLE,
0: Change to read 1 in 16th line on left-hand side in H0 column,
- Schematic 20,
A7U14: Change neumonics of IC as follows:
- | IC Pin No. | Neumonic |
|------------|----------|
| 1 | G |
| 2 | F |
| 3 | E |
| 4 | D |
| 5 | A |
| 6 | B |
| 7 | C |
| 9 | Y4 |
| 10 | Y3 |
| 11 | Y2 |
| 12 | Y1 |
| 13 | ME1 |
| 14 | ME2 |
| 15 | H |
- Schematic 21,
A7R61: Change value to 680.
A7CR4: Change symbol to resistor. Designate R87, 10 ohms.
A7R62: Change value to 8250.
A7R64: Change value to 47K.
A7R82: Change value to 680.
A7CR3: Change symbol to resistor. Designate R88, 10 ohms.
A7R1: Change value to 8250.
A7R86: Change value to 47K.
A7C11: Change value to 440.
Add: A7R89 (10K) from ground to junction of A7C12/A7U19A.
A7R36: Change value to 10K.
A7R32: Change value to 680.
A7R34: Change value to 8250.
A7R35: Change value to 47K.



OPERATING NOTE CHANGES

MODEL 10231B

SIX BIT DATA PROBE

Operating Note Printed: AUGUST 1974

Make all changes listed below as Errata. Check the following table for your instrument serial prefix and/or serial number and make listed change(s) to the operating note:

Serial Prefix or Number	Make Changes	Serial Prefix or Number	Make Changes

△ ERRATA

Page 2,

Add: Paragraph 8a as follows:

8a. A pod clip is also supplied with the clock probe. It is intended to be snapped to the coaxial cable behind the circuit pod. The clip can be attached to any secure fixture. The pod clip is used to support the weight of the circuit pod, removing the weight from the hook-type probe assemblies.

Page 3, figure 3,

U1: Pin 2 should read 3, and pin 3 should read 2.
U4: Pin 2 should read 3, and pin 3 should read 2.

Page 4, table 2,

CP1 thru CP6: Change description to
PROBE ASSY: Hook Type.

MP6: Change HP Part No. and Mfr Part No. to
1540-0320.

Add: MP7, HP Part No. 5040-0538, HANGER:
Circuit Pod, Mfr Code 28480, Mfr Part No.
5040-0538.

W1: Change reference designator to A1W1, and change
HP Part No. and Mfr Part No. to 10231-61618.

Page 4, table 2, (Cont'd),

W8: Change to HP Part No. 10231-61619,
CABLE: Ground 6 in. with Hook-type Probe
Assy, Mfr Code 28480, Mfr Part No. 10231-61619.

Add: W9, HP Part No. 10231-61617,
CABLE: Ground 6 in. with alligator clip, Mfr Code
28480, Mfr Part No. 10231-61617.

A1C14 thru A1C19: In description change 0.47 μ F
to read 0.01 μ F.

A1C20: In description change 0.01 μ F to read
0.47 μ F.

A1E1 thru A1E6: Change description to
NUT: Cable Connector With Bead.

A1E7: Change description to NUT: Cable
Connector Without Bead.

A1L1 thru A1L6: Delete. These are parts of
A1E1 thru A1E6.

12 March 1975

△ = Latest additions to this change sheet.

This change sheet supersedes all prior change sheets for this operating note.

Supplement A for
10231-90903